

ENG BROCHURE

on the proper use of shoe cover model No. SHOECOVER-PRO

Imported by ROCK SAFETY Kft.

5100 Jászberény, Nagykátai Street 10., Hungary

Type of the personal protective equipment:

ESD, cleanroom, anti-slip, disposable shoe cover

Model No.: SHOECOVER-PRO

Certificate serial numbers: CER20250206-1, CER20250203-19

Notified body involved in the conformity:

GOD-MIN ENGINEERING LTD.

2800 Tatabánya, Cseresznyefa Street. 60/3., Hungary

Declaration of conformity – ID: SHOECOVER-PRO-4

– Available: rocksafety.com

HUN TÁJÉKOZTATÓ

a SHOECOVER-PRO cipővédő rendeltetésszerű használatához

Importőr: ROCK SAFETY Kft.

5100 Jászberény, Nagykátai út 10., Magyarország

A védőeszköz megnevezése: ESD, tisztateres, csúszásmentes, egyszer használatos cipővédő

Cikkszám: SHOECOVER-PRO

Tanúsítványok sorszáma: CER20250206-1, CER20250203-19

A megfelelőségértékelést végző bejelentett szervezet:

GOD-MIN MÉRNÖKI KFT.

2800 Tatabánya, Cseresznyefa u. 60/3.

Megfelelőségi nyilatkozat – Azonosító: SHOECOVER-PRO-4

– Elérhető: rocksafety.com

- Material: 100% non-woven polypropylene (PP).
- ESD: Full sole-length (70 cm) conductive grounding ribbon with 35 cm + free-hanging section.
- Material of the conductive ribbon: 100% polyethylene (PE).
- Surface resistance of the conductive ribbon (Rs): $<1 \times 10^6 \Omega$.
- Two-point resistance of the conductive ribbon (Rpp): $<35 \times 10^6 \Omega$.
- Clean room classifications (ISO 14644): ISO 6 / ISO 7 / ISO 8.
- Anti-slip sole patterns.
- Elasticated opening.
- Dimensions: 41x17 cm.
- Light weight: 35 g/m².
- Easy and safe solution for visitors of electrostatically protected areas (EPA).
- Easy fit for various shoe styles and sizes.
- Manual put-on.
- Colour: blue.
- Packaging: 100 pcs/package.

USE Shoe covers are common items of personal protective equipment (PPE) within the medical, cleanroom, chemical, industrial, laboratory, and emergency environments. Such environments often require shoe covers as part of standard PPE protocols.

Put on and wear:

1. Hold the opening of the shoe cover.
2. Place the toe of your footwear at the front of the shoe cover.
3. Pull the rubber of the shoe cover to the back of the footwear and insert the heel of the footwear into the back of the shoe cover.
4. Make sure the footwear is covered appropriately.
5. Make sure the ESD strip is stuffed into your sock or shoe, so they are not hanging out.

Put on your both shoe covers. Make sure that all areas of the foot are covered and the boot or shoe covers are snug over your ankle and calf. Wrap the ESD strap around for a comfortable fit. Try not to touch the floor or other areas with your hands while putting the shoe/boot covers on.

Only use the cover on clean and dry footwear. Only an intact and dry shoe cover will provide adequate protection. If a defective shoe cover is found it should be damaged noticeably and not used. The shoe cover is for single use only, do not reuse.

CLEANING, MAINTENANCE Cannot be washed or cleaned.

STORAGE Under airy, dry, cool and dark conditions; in the original packaging.

- Alapanyag: 100% nem szőtt polipropilén (PP).
- ESD: Teljes talprészen végigfutó (70 cm), vezetőképes földelő szalag 35 cm + szabadonálló résszel.
- A vezetőképes szalag alapanyaga: 100% polietilén (PE).
- A vezetőképes szalag felületi ellenállása (Rs): $<1 \times 10^6 \Omega$.
- A vezetőképes szalag kétpontos ellenállása (Rpp): $<35 \times 10^6 \Omega$.
- Tisztateres besorolás (ISO 14644): ISO 6 / ISO 7 / ISO 8.
- Csúszásmentes talpmintázat.
- Gumírozott bokarész.
- Méret: 41x17 cm.
- Könnyű: 35 g/m².
- Egyszerű és biztonságos megoldás az elektrosztatikusan védett területek (EPA) látogatói számára.
- Bármilyen lábbelire és lábméretre alkalmas.
- Manuálisan felvehető.
- Szín: kék.
- Csomagolás: 100 db/csomag.

HASZNÁLAT A cipővédők gyakori egyéni védőeszközök (PPE) az orvosi, tisztatéri, vegyi, ipari, laboratóriumi és vészhelyzeti környezetben. Az ilyen helyeken a szabványos PPE előírások szerint gyakran cipővédőre van szükség.

Felvétel és viselés:

1. Fogja meg a cipővédő nyílását!
2. Helyezze a lábbeli orrát a cipővédő elejébe!
3. Húzza a cipővédő gumiját a lábbeli hátuljához, és helyezze be a lábbeli sarkát a cipővédő hátuljába!
4. Győződjön meg róla, hogy a lábbeli mindenhol megfelelően fedve van!

5. Ügyeljen arra, hogy a ESD szalagok úgy legyenek betűrtve a zoknijába vagy a cipőjébe, hogy ne lógjanak ki!

Vegye föl mindkét cipővédőt! Győződjön meg róla, hogy a láb minden része le van fedve, és a nyílás szorosan illeszkedik a bokához! Tekerje körbe az ESD szalagot a kényelmes illeszkedés érdekében! Ügyeljen arra, hogy ne érintse meg a kezével a padlót vagy más területeket, miközben felveszi a cipővédőt!

Csak tiszta, száraz lábbelire húzzunk fel cipővédőt! Csak teljesen ép, sértetlen, száraz cipővédő biztosít megfelelő védelmet és vehető használatba. Az elkoszolódott, sérült cipővédőt le kell cserélni. A cipővédő egyszeri használatra szolgál, ne használja újra!

TISZTÍTÁS, KARBANTARTÁS Nem mosható, nem tisztítható.

TÁROLÁS Szellős, száraz, hűvös helyen, fénytől védve, eredeti csomagolásban kell tárolni.



IEC 61340-5-1



ISO 14644



rocksafety.com

Made in China



5 996831 336744

